

KENEX DPC

Kitchen plate degreaser

CHARACTERISTICS

Vigorous surface degreaser of high alkalinity indicated for cleaning and degrease burned fat, in kitchen plates. Its formulation facilitates a fast action on fats residues, allowing its fast elimination.

HOW TO USE

Extend the product with the help of a spatula on the hot plate and let it act for 2 or 3 minutes. Then rinse with water, spilling it over the plate and removing. As the water evaporates, the fat is loose, retire it and rinse with abundant water.

PHYSICAL AND CHEMICAL PROPERTIES

Appearance	Liquid
Colour	Brown/ Reddish
Odour	Odourless
pH (10 %)	13
Density (20 °C)	1140 kg/m ³
Solubility	Soluble in water

PRESENTATION

1, 5, 10 and 20 litres containers

PRECAUTIONS



Hazard statements: Skin Corr. 1: H314 – Causes severe skin burns and eye damage.

Precautionary statements: P280: Wear protective gloves/protective clothing/eye protection/face protection. P301+P330+P331: IF SWALLOWED: rinse mouth. Do NOT induce vomiting. P303+P361+P353: IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. P304+P340: IF INHALED: Remove person to fresh air and keep comfortable for breathing. P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P310 Immediately call a POISON CENTER or doctor/physician. Do not ingest. Keep out of the reach of children. In case of accident, consult to the Medical Service of Toxicological Information Tel. 0034 915 620 420.

Substances that contribute to the classification: Sodium hydroxide.

ADDITIONAL INFORMATION

While the above information is correct to our criteria, as the conditions of use of the product are beyond our control, we disclaim any responsibility for incorrect use of the product.