Data sheet



DELENEX AD BOX+C

Dishwasher polisher for high hardness waters Super concentrate BOX+C system

CHARACTERISTICS

DELENEX AD BOX+C is used in the polishing of dishes, glassware and cutlery in bars, restaurants, dining rooms, hotels, etc.

It is an additive for the rinse water at the end of the washing process, which due to its extraordinary concentration of active matter is dosed in small doses, facilitating the drying and polishing of the washed parts and avoiding the formation of calcareous encrustations. Its active ingredients reduce the surface tension of water, causing a uniform film to form on washed objects, allowing it to drain without leaving marks or veils on the surface and achieving a very fast drying time.

It is recommended for use in hard or extremely hard water.

HOW TO USE

Connect the container directly to the dispenser of the circuit of rinsing of the dishwasher, to a temperature of 80-90 °C.

Dose it at 0,07-0,15 ml/l, increasing the dosage proportionally to the hardness of the water.

PHYSICAL AND CHEMICAL PROPERTIES

Appearance Transparent liquid

Colour Blue

Odour Characteristic

pH 3,13

Density (20 °C) 1123 kg/m³
Water solubility Soluble in water

PRESENTATION

Box with 10 liter bag

PRECAUTION

Hazard indications: Eye Irrit. 2: H319 - Causes serious eye irritation. Skin Irrit. 2: H315 - Causes skin irritation.

Warning



Cautionary advice: P264: Wash thoroughly after use. P280: Wear protective gloves/protective clothing/eye protection/face protection. P302+P352: IF ON SKIN: Wash with plenty of water. P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P332+P313: If skin irritation occurs: Get medical advice/attention. P337+P313: If eye irritation persists: Get medical advice/attention. Before using the product, read the label carefully. Do not ingest. In case of accident, consult to the Medical Service of Toxicological Information Tel. 0034 915 620 420.

ADDITIONAL INFORMATION

While the above information is correct to our criteria, as the conditions of use of the product are beyond our control, we disclaim any responsibility for incorrect use of the product.

Version: 23-001 Date: 14.07.2023