

## DELENEX CRISTAL-50

Automatic dishwasher  
for hard water. Special glasses

### CHARACTERISTICS

It's an alkaline detergent of high performance and controlled foam for washing of crockery and glassware in all types of automatic dishwashers, indicated in areas with high water hardness (40-60 °F).

Formulated with high alkalinity agent's, high content of lime sequestrants and saponifying power, DELENEX CRISTAL-50 gives a great power of cleaning and degrease, removes all dirt, organic waste and pigmentation spots caused by food remains, whether they are dairy, protein, coffee, tea, wine, etc. and achieving total hygiene.

At the indicated doses, it avoids calcareous encrustations in the machine and objects to be washed, providing, due to its special characteristics, an additional care and shine to the glassware.

### HOW TO USE

Dose 2-4 ml of the product per litre of water, indicative amount depending on the dirt to remove and water hardness. In machines with automatic dosing system, connect directly the doser's intake to the detergent container. It is recommended to work at a temperature between 55-65°C and follow the instructions of the machine.

### PHYSICAL AND CHEMICAL PROPERTIES

Appearance	Transparent liquid
Colour	Dark yellow
Odour	Characteristic
pH (10 %)	13
Density (20 °C)	1192 kg/m <sup>3</sup>
Water solubility	Easily soluble in water

### PRESENTATION

5, 10 and 20 litres container

### PRECAUTION



**Hazard statements:** Skin Corr. 1: H314 – Causes severe skin burns and eye damage. Met. Corr. 1: H290 - May be corrosive to metals.

**Precautionary statements:** P234: Keep only in original packaging. P280: Wear protective gloves/protective clothing/eye protection/face protection. P301+P330+P331: IF SWALLOWED: rinse mouth. Do NOT induce vomiting. P303+P361+P353: IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. P304+P340: IF INHALED: Remove person to fresh air and keep comfortable for breathing. P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Restricted to professional users. Keep only in the original container. Do not ingest. Keep out of the reach of children. In case of accident, consult to the Medical Service of Toxicological Information Tel. 0034 915 620 420.

**Substances that contribute to the classification:** Potassium hydroxide; sodium hydroxide.

### ADDITIONAL INFORMATION

While the above information is correct to our criteria, as the conditions of use of the product are beyond our control, we disclaim any responsibility for incorrect use of the product.