Data sheet



DELENEX DR

Automatic dishwasher detergent Hard water

CHARACTERISTICS

It's an alkaline detergent of high performance and controlled foam for washing of crockery and glassware in all types of automatic dishwashers, indicated in areas with water up to 60 °F lime.

Formulated with high alkalinity agent's, high content of lime sequestrants and saponifying power, DELENEX DR gives a great power of cleaning and degrease, removes all dirt, organic waste and pigmentation spots caused by food remains, whether they are dairy, protein, coffee, tea, wine, etc. and achieving total hygiene.

Thanks to its sequestering effect, prevents scale deposits in the machine and objects to be cleaned.

HOW TO USE

Dose 2-4 g per liter of water, depending on the soiling and water hardness.

In automatic dosing machines, connect directly to the outlet of the dosing detergent container.

It's recommended to work at a temperature between 55-65 °C and follow the instructions on the machine.

PHYSICAL AND CHEMICAL PROPERTIES

Appearance Colour Odour pH (10 %) Density (20 °C) Solubility in water Transparent liquid Brown Characteristic 13 1170 kg/m³ Soluble in water

PRESENTATION

5, 10 and 20 litres containers

PRECAUTIONS



Hazard statements: Met. Corr. 1: H290 - May be corrosive to metals. Skin Corr. 1: H314 - Causes severe skin burns and eye damage.

Precautionary statements: P234: Keep only in original container. P280: Wear protective gloves/protective clothing/eye protection/face protection. P301+P330+P331: IF SWALLOWED: rinse mouth. Do NOT induce vomiting. P303+P361+P353: IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water or shower. P304+P340: IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Do not ingest. Keep out of reach of children. Restricted to professional users. Keep only in the original container. In case of accident, consult to the Medical Service of Toxicological Information Tel. 0034 915 620 420.

Substances that contribute to the classification: Sodium hydroxide.

ADDITIONAL INFORMATION

While the above information is correct to our criteria, as the conditions of use of the product are beyond our control, we disclaim any responsibility for incorrect use of the product.

CHRISTEYNS ESPAÑA SLU

C/ Científica Margarita Salas Falgueras, 2 - 46729 Ador (Valencia) Spain T +34 962 871 345 E info.es@christeyns.com W www.christeyns.com