

## DELENEX DR BOX+C

Automatic dishwasher detergent high  
hardness water  
Super concentrate BOX+C system

### CHARACTERISTICS

DELENEX DR BOX+C is used in automatic washing of dishes, glassware and cutlery in bars, restaurants, dining rooms, hotels, etc.

Due to its extraordinary concentration of active matter, dosed in small doses, it quickly and efficiently removes the most encrusted dirt: fats, adhering food residues, starches, etc.

Foam-free product under conditions of use and formulated with a high percentage of calcium sequestrants, necessary for perfect operation in high hardness waters, which act by complexing the calcium ions present in the water, avoiding the precipitation of salts in hard waters, allowing their use in any hardness of water.

It is not aggressive with porcelain, glass or cutlery.

### HOW TO USE

Add the diluted detergent between 1-2 ml/l, by means of automatic dispenser, in the bath of washing of the dishwasher, to a temperature of 55-65 °C. Increase the dose proportionally to the hardness of the water and dirt to eliminate.

### PHYSICAL AND CHEMICAL PROPERTIES

Appearance	Transparent liquid
Colour	Green
pH (1 %)	12,64
Density (20 °C)	1340 kg/m <sup>3</sup>
Water solubility	Soluble in water

### PRESENTATION

Box with 10 liter bag

### PRECAUTION



**Hazard statements:** Skin Corr. 1: H314 - Causes severe skin burns and eye damage.

**Precautionary statements:** P280: Wear protective gloves/protective clothing/eye protection/face protection. P301+P330+P331: IF SWALLOWED: rinse mouth. Do NOT induce vomiting. P303+P361+P353: IF ON SKIN (or hair): Remove/Take off immediately all contaminated clothing. Rinse skin with water/shower. P304+P340: IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P310: Immediately call a poison center/doctor.

Do not ingest. Keep out of the reach of children. Restricted to professional users. Keep only in the original container. In case of accident, consult to the Medical Service of Toxicological Information Tel. 0034 915620420.

**Substances that contribute to the classification:** Sodium hydroxide.

### ADDITIONAL INFORMATION

While the above information is correct to our criteria, as the conditions of use of the product are beyond our control, we disclaim any responsibility for incorrect use of the product.