

# LAVAPER COMTE

Surfactant component for textile washing

## CHARACTERISTICS

Liquid detergent for textile washing, excellent results in both hot and cold water, taking into account that the higher the temperature is, the greater its effectiveness will be.

Formulated with optical brighteners that enhance the whiteness of the tissues, leaves the clothes clean, deodorized, with a nice touch and slightly perfumed.

It is recommended to have a special care with delicate textiles (viscose, wool, silk, etc.) checking the result of the action of the detergent in an inconspicuous area before.

# HOW TO USE IT

Specially formulated for automatic dosing systems, it is used in combination with any of our alkaline components, LAVAPER AC or LAVAPER BASICO, making up an effective washing detergent.

Dose accordance with the following doses, depending on the dirt and hardness of the water: Soft water: 4-8 ml/kg of dry clothes.

Semi-hard water: 5-10 ml/kg of dry clothes.

Hard water: 6-12 ml/kg of dry clothes.

For manual dosing pre-dilute the detergent at 10% with water.

### PHYSICAL AND CHEMICAL PROPERTIES

Appearance	Liquid
Colour	Blue
Odour	Characteristic
pH (10%)	9,2
Density (20°C)	1000 kg/m <sup>3</sup>
Solubility	Easily soluble in water

# PRESENTATION

20 litres containers

### PRECAUTION



**Hazard statements:** Eye Dam. 1: H318 – Causes serious eye damage **Precautionary statements:** P280: Wear protective gloves/protective clothing/eye protection/face protection. P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do – continue rinsing. P310: Immediately call a poison center/doctor. Do not ingest. Keep out of the reach of children. In case of accident, consult to the Medical Service of Toxicological Information Tel. 0034 915620420.

**Substances that contribute to the classification:** Alcohols, C12-15, branched and linear ethoxylated; Potassium dodecylbenzenesulphonate.

### ADDITIONAL INFORMATION

While the above information is correct to our criteria, as the conditions of use of the product are beyond our control, we disclaim any responsibility for incorrect use of the product.

#### **CHRISTEYNS ESPAÑA SLU**

C/ Científica Margarita Salas Falgueras, 2 - 46729 Ador (Valencia) Spain T +34 962 871 345 E info.es@christeyns.com W www.christeyns.com